

SPECIAL AGG HOPPER FULL TILT SWITCH CONTROL

Part Number: 25633

DESCRIPTION:

This option provides controls to stop the aggregate belt when the aggregate hopper is full.

OPERATION:

Automatic

When the HOPPER FULL input comes on, the batching system stops the aggregate belt.

Manual

Not Applicable.

SYSTEM REQUIREMENTS:

- HOPPER FULL Input - an unassigned I/O position that is controlled by a pushbutton or LED on the Manual Station.

IMPLEMENTATION:

- Install the Opto module in the correct slot in the J-Box.
- Configure the pushbutton, if applicable, on the Manual Station.

www.commandalkon.com

Command Alkon Headquarters

1800 International Park Drive, Suite 400

Birmingham, Alabama 35243

Phone: 1-205-879-3282

Toll Free: 1-800-624-1872

Fax: 1-205-870-1405