

PLANT DUST COLLECTOR CONTROL, AUTOMATIC

Part Number: 23831

DESCRIPTION:

This option provides control for a central dust collection system.

OPERATION:***Automatic***

- The central dust collector starts when discharge is authorized for the load.
- The central dust collector stops when all scales are finished discharging.

Manual

- The operator presses the maintained DUST COLL pushbutton on the Manual Station to start the central dust collector.
- The central dust collector continues running until the operator presses the pushbutton again to deactivate it.

SYSTEM REQUIREMENTS:

- DUST COLL output - an unassigned I/O position controlled by a pushbutton on the Manual Station.

IMPLEMENTATION:

- Install the Opto module in the correct slot in the J-Box.
- Configure the DUST COLL pushbutton on the Manual Station.
- Configure the I/O, Extra Device and Sequences in the batching system.

www.commandalkon.com

Command Alkon Headquarters

1800 International Park Drive, Suite 400
Birmingham, Alabama 35243
Phone: 1-205-879-3282
Toll Free: 1-800-624-1872
Fax: 1-205-870-1405