

MIXER LOAD METER – 4” DOOR MOUNTED

Part Number: 15171

DESCRIPTION:

This option provides an analog meter mounted in the J-Box door that displays the current draw on the mixer. The meter is heavily dampened to prevent fluctuations in readings. Does not include the current transformer. Takes in 0-5 amp. Meter deflection is 0-150 amp.

OPERATION:

- When the mixer is running, the load meter displays the current draw (in amps) on the mixer.

SYSTEM REQUIREMENTS:

- The load meter is mounted in the J-Box at the Command Alkon factory.

IMPLEMENTATION:

- Wire the load meter to the current transformer.

www.commandalkon.com**Command Alkon Headquarters**

1800 International Park Drive, Suite 400

Birmingham, Alabama 35243

Phone: 1-205-879-3282

Toll Free: 1-800-624-1872

Fax: 1-205-870-1405