

## **WEIGHED WATER CONTROL**

**Part Number: 23815**

### **DESCRIPTION:**

This option replaces the standard metered water control and provides control for feeding weighed water into a single scale.

### **OPERATION:**

#### ***Automatic***

- When released by the feed sequence, water is fed into the water scale and weighed up. Feeding deactivates when the target weight is reached (and is within tolerance). If additional waters are required, these are systematically fed into the scale.

#### ***Manual***

- The operator pushes the WAT FEED button on the Manual Station to feed water into the water scale. Feeding continues as long as the feed button is depressed.

### **SYSTEM REQUIREMENTS:**

- WAT CLOSED - an unassigned LED or pushbutton on the Manual Station.
- WAT DISCH - an unassigned pushbutton on the Manual Station.

### **IMPLEMENTATION:**

- Install the Opto module(s) in the correct slot(s) in the J-Box.
- Configure the Manual Station pushbuttons.
- Configure a Water Scale.
- Set up the Water Bin(s).

**[www.commandalkon.com](http://www.commandalkon.com)**

### **Command Alkon Headquarters**

1800 International Park Drive, Suite 400

Birmingham, Alabama 35243

Phone: 1-205-879-3282

Toll Free: 1-800-624-1872

Fax: 1-205-870-1405